
Wounded Paw Black Wolf Guitar Distortion

High gain chainsaw ripping guitar distortion inspired by the HM-2. The distortion section with two clipping stages has a wide range of gain set by the DRIVE control. The EQ features two bands of boost or cut with variable center frequencies.



Controls

IN – Instrument input.

OUT – Output to amplifier.

LO – Boost or cut to the low range. The noon position is flat, no boost or cut.

LO RANGE – Sets the center frequency of the LO boost or cut, from 100Hz to 700Hz.

HI RANGE – Sets the center frequency of the HI boost or cut, from 800Hz to 3kHz.

HI – Boost or cut to the low range. The noon position is flat, no boost or cut.

DRIVE – Amount of gain for the distortion.

TREBLE – Rolls off the high end of the output signal.

VOLUME - Master volume of the Black Wolf sent to the OUT.

9V DC JACK – The Black Wolf can be powered by a 9V battery or by a standard 9V power adaptor, such as the Boss PSA or One Spot. The jack must have a center negative connection. If using a battery, remove the patch cord from the IN jack when not in use to disconnect the battery and save battery life.

Wounded Paw Audio 26C Brookfield St. Toronto, ON M6J 3A9 Canada



www.woundedpawaudio.ca